



**Super Wedgie
Part #48576**

WARNING:

Failure to read and follow instructions on the use of this product may result in serious injury.

General Directions:

Place Super Wedgie on roof only after the first several row of shingles have been nailed down. After insuring that the foam has gripped asphalt shingles, place bundle of shingles on Super Wedgie tray. Bundle should rest against the angled lip. When moving Super Wedgie and shingle bundle to the next location, lift tray and use raised skid plate to safely slide across roof. Do not use for roof pitches over 6/12.